

INSTALLATION INSTRUCTIONS

Air Conditioner



This air conditioner uses the refrigerant R410A.

Model No.

Indoor Units		Nominal Capacity		
Type	Indoor Unit Type	26	36	42
T2	Ceiling	S-26PT2U6	S-36PT2U6	S-42PT2U6

Read through the Installation Instructions before you proceed with the installation.
In particular, you will need to read under the “IMPORTANT!” section at the top of the page.

IMPORTANT! Please Read Before Starting

This air conditioning system meets strict safety and operating standards. As the installer or service person, it is an important part of your job to install or service the system so it operates safely and efficiently.

For safe installation and trouble-free operation, you must:

- Carefully read this instruction booklet before beginning.
- Follow each installation or repair step exactly as shown.
- This air conditioner shall be installed in accordance with National Wiring Regulations.
- Pay close attention to all warning and caution notices given in this manual.



WARNING

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



CAUTION

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

If Necessary, Get Help

These instructions are all you need for most installation sites and maintenance conditions. If you require help for a special problem, contact our sales/service outlet or your certified dealer for additional instructions.

In Case of Improper Installation

The manufacturer shall in no way be responsible for improper installation or maintenance service, including failure to follow the instructions in this document.

SPECIAL PRECAUTIONS



WARNING

When Wiring



ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH. ONLY A QUALIFIED, EXPERIENCED ELECTRICIAN SHOULD ATTEMPT TO WIRE THIS SYSTEM.

- Do not supply power to the unit until all wiring and tubing are completed or reconnected and checked.
- Highly dangerous electrical voltages are used in this system. Carefully refer to the wiring diagram and these instructions when wiring. Improper connections and inadequate grounding can cause **accidental injury or death**.
- **Ground the unit** following local electrical codes.
- Connect all wiring tightly. Loose wiring may cause overheating at connection points and a possible fire hazard.
- To prevent possible hazards from insulation failure, the unit must be grounded. 
- This equipment is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD). Otherwise, it may cause electrical shock and fire in case of equipment breakdown or insulation breakdown.

When Transporting

Be careful when picking up and moving the indoor and outdoor units. Get a partner to help, and bend your knees when lifting to reduce strain on your back. Sharp edges or thin aluminum fins on the air conditioner can cut your fingers.

When Installing...

Select an installation location which is rigid and strong enough to support or hold the unit, and select a location for easy maintenance.

...In a Room

Properly insulate any tubing run inside a room to prevent "sweating" that can cause dripping and water damage to walls and floors.



CAUTION

Keep the fire alarm and the air outlet at least 5 feet (1.5 m) away from the unit.

...In Moist or Uneven Locations

Use a raised concrete pad or concrete blocks to provide a solid, level foundation for the outdoor unit. This prevents water damage and abnormal vibration.

...In an Area with High Winds

Securely anchor the outdoor unit down with bolts and a metal frame. Provide a suitable air baffle.

...In a Snowy Area (for Heat Pump-type Systems)

Install the outdoor unit on a raised platform that is higher than drifting snow. Provide snow vents.

When Connecting Refrigerant Tubing

- Pay particular attention to refrigerant leakages.
- Ventilate the room immediately, in the event that is refrigerant gas leaks during the installation. Be careful not to allow contact of the refrigerant gas with a flame as this will cause the generation of toxic gas.
- Keep all tubing runs as short as possible.
- Apply refrigerant lubricant to the matching surfaces of the flare and union tubes before connecting them, then tighten the nut with a torque wrench for a leak-free connection.
- Check carefully for leaks before starting the test run.



WARNING

- When performing piping work, do not mix air except for specified refrigerant (R410A) in refrigeration cycle. It causes capacity down, and risk of explosion and injury due to high tension inside the refrigerant cycle.
- If the refrigerant comes in contact with a flame, it produces a toxic gas.
- Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury, etc.

- Do not leak refrigerant while piping work for an installation or re-installation, and while repairing refrigeration parts.
Handle liquid refrigerant carefully as it may cause frostbite.

When Servicing

- Turn the power OFF at the main power box (mains) before opening the unit to check or repair electrical parts and wiring. 
- Keep your fingers and clothing away from any moving parts.
- Clean up the site after you finish, remembering to check that no metal scraps or bits of wiring have been left inside the unit.



WARNING

- This product must not be modified or disassembled under any circumstances. Modified or disassembled unit may cause fire, electric shock or injury.
- Do not clean inside the indoor and outdoor units by users. Engage authorized dealer or specialist for cleaning.
- In case of malfunction of this appliance, do not repair by yourself. Contact to the sales dealer or service dealer for a repair.



CAUTION

- Do not touch the air inlet or the sharp aluminum fins of the outdoor unit. You may get injured. 
- Ventilate any enclosed areas when installing or testing the refrigeration system. Leaked refrigerant gas, on contact with fire or heat, can produce dangerously toxic gas.
- Confirm after installation that no refrigerant gas is leaking. If the gas comes in contact with a burning stove, gas water heater, electric room heater or other heat source, it can cause the generation of toxic gas.

Others



WARNING

- Do not sit or step on the unit, you may fall down accidentally. 



CAUTION

- Do not touch the air inlet or the sharp aluminum fins of the outdoor unit. You may get injured. 
- Do not stick any object into the FAN CASE. You may be injured and the unit may be damaged. 



Check of Density Limit

The room in which the air conditioner is to be installed requires a design that in the event of refrigerant gas leaking out, its density will not exceed a set limit.

The refrigerant (R410A), which is used in the air conditioner, is safe, without the toxicity or combustibility of ammonia, and is not restricted by laws imposed to protect the ozone layer. However, since it contains more than air, it poses the risk of suffocation if its density should rise excessively. Suffocation from leakage of refrigerant is almost non-existent. With the recent increase in the number of high density buildings, however, the installation of multi air conditioner systems is on the increase because of the need for effective use of floor space, individual control, energy conservation by curtailing heat and carrying power, etc.

Most importantly, the multi air conditioner system is able to replenish a large amount of refrigerant compared to conventional individual air conditioners.

If a single unit of the multi air conditioner system is to be installed in a small room, select a suitable model and installation procedure so that if the refrigerant accidentally leaks out, its density does not reach the limit (and in the event of an emergency, measures can be made before injury can occur).

ASHRAE and the International Mechanical Code of the ICC as well as CSA provide guidance and define safeguards related to the use of refrigerants, all of which define a Refrigerant Concentration Level (RCL) of 25 pounds (11.3 kg) per 1,000 cubic feet (28.3 m³) for R410A refrigerant.

For additional guidance and precautions related to refrigerant safety, please refer to the following documents:

International Mechanical Code 2012 (IMC-2012)
(or more recently revised)

ASHRAE 15

ASHRAE 34

CONTENTS

	Page		Page
IMPORTANT	2	8. PRECAUTIONS ON TEST RUN	19
Please Read Before Starting		■ Checkpoint	19
Check of Density Limit			
1. GENERAL	5	9. HOW TO INSTALL WIRELESS REMOTE CONTROLLER RECEIVER	20
1-1. Tools Required for Installation (not supplied)		NOTE	
1-2. Accessories Supplied with Unit		Refer to the Operating Instructions attached to the optional	
1-3. Type of Copper Tube and Insulation Material		Wireless Remote Controller Receiver.	
1-4. Additional Materials Required for Installation			
2. SELECTING THE INSTALLATION SITE	6	10. APPENDIX	20
2-1. Indoor Unit		■ Care and Cleaning	
3. HOW TO INSTALL THE INDOOR UNIT	7	■ Troubleshooting	
■ Ceiling Type (Type T2)	7	■ Tips for Energy Saving	
3-1. Required Minimum Space for Installation and Service			
3-2. Preparation Before Installation			
3-3. Suspending the Indoor Unit			
3-4. Duct for Fresh Air			
3-5. Shaping the Tubing			
3-6. Installing the Drain Pipe			
4. ELECTRICAL WIRING	11		
4-1. General Precautions on Wiring			
4-2. Recommended Wire Length and Wire Diameter for Power Supply System			
4-3. Wiring System Diagrams			
5. HOW TO PROCESS TUBING	15		
5-1. Connecting the Refrigerant Tubing			
5-2. Connecting Tubing Between Indoor and Outdoor Units			
5-3. Insulating the Refrigerant Tubing			
5-4. Taping the Tubes			
5-5. Finishing the Installation			
6. FINAL PROCEDURE	18		
7. HOW TO INSTALL THE TIMER REMOTE CONTROLLER OR HIGH-SPEC WIRED REMOTE CONTROLLER (OPTIONAL PART)	18		
NOTE			
Refer to the Operating Instructions attached to the optional Timer Remote Controller or optional High-spec Wired Remote Controller.			

1. GENERAL

This booklet briefly outlines where and how to install the air conditioning system. Please read over the entire set of instructions for the indoor and outdoor units and make sure all accessory parts listed are with the system before beginning.

1-1. Tools Required for Installation (not supplied)



1. Flathead screwdriver
2. Phillips head screwdriver
3. Knife or wire stripper
4. Tape measure
5. Carpenter's level
6. Sabre saw or keyhole saw
7. Hacksaw
8. Core bits
9. Hammer
10. Drill
11. Tube cutter
12. Tube flaring tool
13. Torque wrench
14. Adjustable wrench
15. Reamer (for deburring)



1-2. Accessories Supplied with Unit

The accessory parts are supplied inside the indoor unit. Open the air-intake grille of the indoor unit and take out a package of accessories. See the section "3-2. Preparation Before Installation".

Table 1-1 (Ceiling)

Part Name	Figure	Q'ty	Remarks
Special washer		4	For temporarily suspending indoor unit from ceiling
Drain insulator		2	For drain hose joint
Flare insulator		1	For gas tube joint
		1	For liquid tube joint
Clamper		4	For flare insulator
Clamper		1	For wiring
Drain hose		1	For main unit + PVC pipe joints
Hose band		1	For drain hose connection
Screw		2	For side cover (L/R)

Part Name	Figure	Q'ty	Remarks
Side cover (R)		1	(Packed in carton box) For right side
Side cover (L)		1	(Packed in carton box) For left side

Part Name	Figure	Q'ty	Remarks
Full-scale installation diagram		1	For positioning installation
Wire cover		1	For control box
Screw		1	For wire cover

Part Name	Figure	Q'ty	Remarks
Operating Instructions		1	
Installation Instructions		1	
Warranty card		1	

- Use 3/8" (M10) for suspension bolts.
- Field supply for suspension bolts and nuts.

1-3. Type of Copper Tube and Insulation Material

If you wish to purchase these materials separately from a local source, you will need:

1. Deoxidized annealed copper tube for refrigerant tubing.
2. Foamed polyethylene insulation for copper tubes as required to precise length of tubing. Wall thickness of the insulation should be not less than 5/16" (8 mm).
3. Use insulated copper wire for field wiring. Wire size varies with the total length of wiring. Refer to "4. ELECTRICAL WIRING" for details.



Check local electrical codes and regulations before obtaining wire. Also, check any specified instructions or limitations.

1-4. Additional Materials Required for Installation

1. Refrigeration (armored) tape
2. Insulated staples or clamps for connecting wire (See your local codes.)
3. Putty
4. Refrigeration tubing lubricant
5. Clamps or saddles to secure refrigerant tubing
6. Scale for weighing

2. SELECTING THE INSTALLATION SITE

2-1. Indoor Unit

AVOID:

- areas where leakage of flammable gas may be expected.
- places where large amounts of oil mist exist.
- direct sunlight.
- locations near heat sources which may affect the performance of the unit.
- locations where external air may enter the room directly. This may cause "condensation" on the air discharge ports, causing them to spray or drip water.
- locations where the remote controller will be splashed with water or affected by dampness or humidity.
- installing the remote controller behind curtains or furniture.
- locations where high-frequency emissions are generated.

DO:

- select an appropriate position from which every corner of the room can be uniformly cooled.
- select a location where the ceiling is strong enough to support the weight of the unit.
- select a location where tubing and drain pipe have the shortest run to the outdoor unit.
- allow room for operation and maintenance as well as unrestricted air flow around the unit.
- install the unit within the maximum elevation difference above or below the outdoor unit and within a total tubing length (L) from the outdoor unit as detailed in the Installation Instructions packed with the outdoor unit.
- allow room for mounting the remote controller about 3.3ft. (1 m) off the floor, in an area that is not in direct sunlight or in the flow of cool air from the indoor unit.




Fig. 2-1

3. HOW TO INSTALL THE INDOOR UNIT

Unit: inch (mm)

■ Ceiling Type (Type T2)

3-1. Required Minimum Space for Installation and Service

(1) Dimensions of suspension bolt pitch and unit

Type	Length	A	B	C
26	inch	48-17/64	50-13/64	9-1/4
	mm	1226	1275	235
36, 42	inch	62-43/64	62-19/32	9-1/4
	mm	1541	1590	235




Fig. 3-1

Unit: inch (mm)

(2) Refrigerant tubing • drain hose position





Fig. 3-2

(3) Unit opening position (Refrigerant tubing • drain hose • power inlet port • remote control wiring inlet port)

Unit: inch (mm)



*1 Use a compass saw, jig saw or similar tool and cut along the indented portion of the side cover and make a hole inside the cover.

*2 When pulling the refrigerant tubing from the upper side, cut along the indented portion and pass the tubing through the hole.

NOTE

Be sure to use sealing putty to seal off the opening to prevent dust.

Fig. 3-3

3-2. Preparation Before Installation

- (1) Remove the bracket (for suspending the indoor unit).
Loose the M8 or 5/16" suspension bolts.
Then remove the bracket. (Fig. 3-4)

NOTE

Loosen the M8 or 5/16" suspension bolts and expose the axis of bolts less than 5/16" (8 mm).




Fig. 3-4

- (2) Remove the air-intake grille before suspending the indoor unit. First, remove 2 attachment screws fixed with the latches. Open the air-intake grille and hold the claws of the hinges on both sides. Then remove the air-intake grille and suspension lug located on the left and right side of the indoor unit.




Fig. 3-5




Fig. 3-6

- (3) Remove the side plate to the tubing side.

Rear & upper side tubing connection	Remove 2 screws. Slide the side plate in the direction of the arrow and remove it.
Right side tubing connection	Do not remove the side plate.




Fig. 3-7

- (4) Remove the center bracket.

When wiring, remove the center bracket if necessary. When wiring is completed, reinstall the center bracket in its original position.




Fig. 3-8

3-3. Suspending the Indoor Unit

NOTE

Since the diagram is made of paper, it may shrink or stretch slightly because of high temperature or humidity. For this reason, before drilling the holes maintain the correct dimensions between the markings.

- (1) If the full-scale installation diagram is placed on the ceiling, the locations of each suspension bolt can be chosen. Take a pencil and mark the drill holes (Fig. 3-9).




Fig. 3-9

- (2) If the full-scale installation diagram is bent at right angle to the ceiling and wall, the locations of the inlet for indoor tubing and wiring are chosen and the locations of each suspension bolt can also be chosen. Take a pencil and mark the drill holes (Fig. 3-10).





Fig. 3-10

NOTE

The dimension when the indoor unit is placed tightly against the wall. When installing away from the wall, drainage gradient should be taken into consideration.

- (3) Drill holes at the 4 points indicated on the full-scale diagram.
- (4) Depending on the ceiling type:
 - a) Insert suspension bolts (Fig. 3-11).
 - or
 - b) Use existing ceiling supports or construct a suitable support (Fig. 3-12).



Suspension bolt (M10 or 3/8") (not supplied)

Fig. 3-11




Fig. 3-12

WARNING

It is important that you use extreme care in supporting the indoor unit from the ceiling. Ensure that the ceiling is strong enough to support the weight of the unit. Before hanging the ceiling unit, test the strength of each attached suspension bolt.

- (5) Screw in the suspension bolts, allowing them to protrude from the ceiling (Figs. 3-11 and 3-12). The distance of each exposed bolt must be of equal length within 1-31/32" (50 mm). (Fig. 3-13)




Fig. 3-13

- (6) Carry out the preparation for suspending the indoor unit. The suspension method varies depending on whether there is a suspended ceiling or not. (Figs. 3-14 and 3-15)
- (7) Suspend the indoor unit as follows:
- a) Install the bracket to the suspension bolt. Stick it onto the ceiling surface. (Fig. 3-14~3-16)




Fig. 3-14




Fig. 3-15




Fig. 3-16

- b) Suspend the indoor unit to the bracket. Tighten the M8 or 5/16" suspension bolts and fix the indoor unit in place. (Fig. 3-17)




Fig. 3-17

NOTE

The ceiling surface is not always level. Confirm that the indoor unit is evenly suspended. For the installation to be correct, leave a clearance of about 1-31/32" (10 mm) between the ceiling panel and the ceiling surface and fill the gap with an appropriate insulation or filler material.

3-4. Duct for Fresh Air (Field supply)

There is a outside air intake duct connection port (cut out hole) at the left-rear of the indoor unit for drawing in fresh air. If it is necessary to draw in fresh air, remove the cover by opening the hole and connecting the duct to the indoor unit through the connection port. (Refer to Fig. 3-3)

3-5. Shaping the Tubing

- The positions of the refrigerant tubing connections are shown in the figure below. (The tubing can be routed in 3 directions.) (Fig. 3-18)
- * When routing the tubing out through the top or right sides, cut out the cover of the top panel and cut notches in the side panel (Refer to Fig. 3-3).




Fig. 3-18

Use a box cutter or similar tool to cut out the part of the cover indicated by the marked area (Fig. 3-19), to match the positions of the tubes. Pass all refrigerant tubes through this hole.




Fig. 3-19

3-6. Installing the Drain Pipe

- Prepare hard PVC pipe for the drain and connect it to the indoor unit drain pipe with the supplied hose band to prevent water leaks.
- Measure the thickness of the wall from the inside to the outside and cut PVC pipe at a slight angle to fit. Insert the PVC pipe in the wall. (Fig. 3-21)

NOTE

The hole should be made at a slight downward slant to the outside.




Fig. 3-20




Fig. 3-21

(1) Drain hose connection

- The drain hose is connected below the refrigerant tubing.
- (2) Installing the drain hose
 - First insert the drain hose (supplied) to the hose band (supplied) and then install the drain hose to the unit drain port.
 - Insert until the drain hose bumps to the end.
 - Attach the hose band to make the fixed portion 45° upper gradient according to a vinyl tape (not supplied) of the drain hose (supplied). (Fig. 3-23)
 - Hose band screw torque is 2.6 - 3.0 lbf-inch (30 - 35 N-cm).
 - Wind the vinyl tape not to blow up the hose band.
 - Connect both the drain hose and PVC pipe (VP20 or similar material, not supplied). Insert until the PVC pipe bumps to the end and adhere with PVC adhesive.

CAUTION

- **Wrap the drain insulator (supplied) between the connection of the drain hose and tubing not to expose the copper tubing. Also, wrap the hose band together. Wrap the hose band with the drain insulator, where the screw is located facing upward (Fig. 3-23). Then, tighten the insulator with a vinyl tape not to cause the detachment. If the tubing parts remain exposed, condensation may occur.**
- **Be sure to use the supplied drain hose.**
- If other commercially available hose bands are used, the drain hose may become pinched or wrinkled and there is danger of water leakage. Therefore be sure to use the supplied hose bands.
- Connect the drain pipe so that it slopes downward from the unit to the outside. (Fig. 3-22)




Fig. 3-22

- Never allow water traps to occur in the course of the piping.
- Insulate any piping inside the room to prevent dripping.
- After the drain piping, pour an appropriate amount of water into the drain pan through the opening on the side of the air discharge port. Check the water draining smoothly.

* If the drain hose is routed through the left side, refer to Fig. 3-18, and follow the procedure above to install the hose.

Reattach the rubber stopper removed earlier onto the right side. The rubber stopper can be inserted easily by using a screwdriver or similar tool to press the stopper into the drain port on the main unit. Press the stopper into the main unit drain port as far as it will go.






Fig. 3-23

CAUTION

The indoor unit should be slightly tilted downward toward the drain pipe connection side as shown in figure below so that the wastewater can flow smoothly without being trapped in the middle. (Fig. 3-24)




Fig. 3-24

4. ELECTRICAL WIRING

4-1. General Precautions on Wiring

- (1) Before wiring, confirm the rated voltage of the unit as shown on its nameplate, then carry out the wiring closely following the wiring diagram.



- (2) This equipment is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD). Otherwise, it may cause electrical shock and fire in case of equipment breakdown or insulation breakdown. Earth Leakage Circuit Breaker (ELCB) must be incorporated in the fixed wiring in accordance with the wiring regulations. The Earth Leakage Circuit Breaker (ELCB) must be an approved 15 A, having a contact separation in all poles.
- (3) To prevent possible hazards from insulation failure, the unit must be grounded.
- (4) Each wiring connection must be done in accordance with the wiring system diagram. Wrong wiring may cause the unit to misoperate or become damaged.
- (5) Do not allow wiring to touch the refrigerant tubing, compressor, or any moving parts of the fan.
- (6) Unauthorized changes in the internal wiring can be very dangerous. The manufacturer will accept no responsibility for any damage or misoperation that occurs as a result of such unauthorized changes.
- (7) Regulations on wire diameters differ from locality to locality. For field wiring rules, please refer to your LOCAL ELECTRICAL CODES before beginning.
You must ensure that installation complies with all relevant rules and regulations.
- (8) To prevent malfunction of the air conditioner caused by electrical noise, care must be taken when wiring as follows:
- The remote control wiring and the inter-unit control wiring should be wired apart from the inter-unit power wiring.
 - Use shielded wires for inter-unit control wiring between units and ground the shield on single side.
- (9) If the power supply cord of this appliance is damaged, it must be replaced by a repair shop designated by the manufacturer, because special-purpose tools are required.

4-2. Recommended Wire Length and Wire Diameter for Power Supply System

Indoor unit

Type	Time delay fuse or circuit capacity
T2	15 A


Control wiring

(A) Inter-unit control wiring (between outdoor and indoor units)	(B) Remote control wiring	(C) Control wiring for group control
AWG #18 (0.75 mm ²) Use shielded wiring*	AWG #18 (0.75 mm ²) Use shielded wiring*	AWG #18 (0.75 mm ²) Use shielded wiring*
Max. 3,280 ft. (Max. 1,000 m)	Max. 1,640 ft. (Max. 500 m)	Max. 650 ft. (Total) (Max. 200 m (Total))

NOTE

* With ring-type wire terminal.

4-3. Wiring System Diagrams



NOTE

- * 1 When the power source is not supplied from the outdoor unit via the inter-unit power line, provide external power source in the indoor unit.
- * 2 Disconnect Switch may be needed by the National/Local code.



ALWAYS COMPLY WITH NATIONAL AND LOCAL CODE REQUIREMENTS.

Fig. 4-1

NOTE

- (1) Refer to Section "4-2. Recommended Wire Length and Wire Diameter for Power Supply System" for the explanation of "A", "B" and "C" in the above diagram.
- (2) The basic connection diagram of the indoor unit shows the 6P terminal board, so the terminal boards in your equipment may differ from the diagram.
- (3) Refrigerant Circuit (R.C.) address should be set before turning the power on.
- (4) Regarding R.C. address setting, refer to the installation instructions supplied with the remote controller (optional). Auto address setting can be executed by remote controller automatically.
- (5) Ensure that the ground shield cable for inter-unit control wiring between outdoor and indoor units should be connected to the outdoor unit.
- (6) For the inter-unit control wiring between the indoor units, be sure to connect between the shield. Then connect it to the shield of inter-unit control wiring between outdoor and indoor units.
- (7) Ensure that the ground shield cable for a remote controller should be connected only to the indoor unit.




Fig. 4-2



CAUTION

Loose wiring may cause the terminal to overheat or result in unit malfunction.

A fire hazard may also occur.

Therefore, ensure that all wiring is tightly connected.

When connecting each power wire to the terminal, follow the instructions on “How to connect wiring to the terminal” and fasten the wire securely with the fixing screw of the terminal board.

How to connect wiring to the terminal

■ For stranded wiring

- (1) Cut the wire end with cutting pliers, then strip the insulation to expose the stranded wiring approx. 3/8" (10 mm) and tightly twist the wire ends. (Fig. 4-3)
- (2) Using a Phillips head screwdriver, remove the terminal screw(s) on the terminal board.
- (3) Using a ring connector fastener or pliers, securely clamp each stripped wire end with a ring pressure terminal.
- (4) Place the ring pressure terminal, and replace and tighten the removed terminal screw using a screwdriver. (Fig. 4-4)
- (5) Confirm the “Checkpoint” under the section “8.PRECAUTIONS ON TEST RUN” after installation of indoor and outdoor units, panels and electrical wiring.




Fig. 4-3




Fig. 4-4

■ Wiring sample

How to install the power supply wiring

1. Insert the power supply wiring and ground wire through the conduit.
2. Lead the power supply wiring and ground wire through the mounting bracket. Then attach the mounting bracket to the conduit with a locknut.
3. Attach the mounting bracket to the electrical component box.
4. Complete the wire process and connect the power supply wiring to the POWER SUPPLY terminals and ground wire with the ground screw.
5. Be sure to conceal the power supply wiring by the wire cover in place.




Fig. 4-5




Fig. 4-6

How to install the remote control wiring and inter-unit control wiring

1. Connect the remote control wiring and inter-unit control wiring to the terminal board as shown in the figure.
2. Fasten the remote control wiring and inter-unit control wiring using the supplied band through the clamper aside the terminals.




Fig. 4-7

5. HOW TO PROCESS TUBING

The liquid tubing side is connected by a flare nut, and the gas tubing side is connected by brazing.

5-1. Connecting the Refrigerant Tubing

Use of the Flaring Method

Many of conventional split system air conditioners employ the flaring method to connect refrigerant tubes which run between indoor and outdoor units. In this method, the copper tubes are flared at each end and connected with flare nuts.

Flaring Procedure with a Flare Tool

- (1) Cut the copper tube to the required length with a tube cutter. It is recommended to cut approx. 1 – 2 ft. (30 - 50 cm) longer than the tubing length you estimate.
- (2) Remove burrs at the end of the copper tube with a tube reamer or a similar tool. This process is important and should be done carefully to make a good flare. (Fig. 5-1)

NOTE

When reaming, hold the tube end downward and be sure that no copper scraps fall into the tube. (Fig. 5-2)

- (3) Remove the flare nut from the unit and be sure to mount it on the copper tube.
- (4) Make a flare at the end of the copper tube with a flare tool. (Fig. 5-3)

NOTE

A good flare should have the following characteristics:

- inside surface is glossy and smooth
- edge is smooth
- tapered sides are of uniform length

Caution Before Connecting Tubes Tightly

- (1) Apply a sealing cap or water-proof tape to prevent dust or water from entering the tubes before they are used.
 - (2) Be sure to apply refrigerant lubricant to the matching surfaces of the flare and union before connecting them together. This is effective for reducing gas leaks. (Fig. 5-4)
 - (3) For proper connection, align the union tube and flare tube straight with each other, then screw in the flare nut lightly at first to obtain a smooth match. (Fig. 5-5)
- Adjust the shape of the liquid tube using a tube bender at the installation site and connect it to the liquid tubing side valve using a flare.




Fig. 5-1




Fig. 5-2




Fig. 5-3




Fig. 5-4




Fig. 5-5

Cautions During Brazing

- Replace air inside the tube with nitrogen gas to prevent copper oxide film from forming during the brazing process. (Oxygen, carbon dioxide and Freon are not acceptable.)
- Do not allow the tubing to get too hot during brazing. The nitrogen gas inside the tubing may overheat, causing refrigerant system valves to become damaged. Therefore allow the tubing to cool when brazing.
- Use a reducing valve for the nitrogen cylinder.
- Do not use agents intended to prevent the formation of oxide film. These agents adversely affect the refrigerant and refrigerant oil, and may cause damage or malfunctions.

5-2. Connecting Tubing Between Indoor and Outdoor Units

- (1) Tightly connect the indoor-side refrigerant tubing extended from the wall with the outdoor-side tubing.

Indoor Unit Tubing Connection ($\ell_1, \ell_2 \dots \ell_{n-1}$)

Indoor unit type		26, 36, 42
Gas tubing	inch	ø5/8
	mm	ø15.88
Liquid tubing	inch	ø3/8
	mm	ø9.52




Fig. 5-6

- (2) To fasten the flare nuts, apply specified torque as at right:

- When removing the flare nuts from the tubing connections, or when tightening them after connecting the tubing, be sure to use a torque wrench and a spanner. (Fig. 5-6)
If the flare nuts are over-tightened, the flare may be damaged, which could result in refrigerant leakage and cause injury or asphyxiation to room occupants.

- For the flare nuts at tubing connections, be sure to use the flare nuts that were supplied with the unit, or else flare nuts for R410A (type 2). The refrigerant tubing that is used must be of the correct wall thickness as shown in the table at right.

Because the pressure is approximately 1.6 times higher than conventional refrigerant pressure, the use of ordinary flare nuts (type 1) or thin-walled tubes may result in tube rupture, injury, or asphyxiation caused by refrigerant leakage.

Tube diameter		Tightening torque approximate	Tube thickness
ø1/4" (ø6.35 mm)	lbf·inch	120 – 160 lbf·inch	1/32"
	N·m	14 – 18 N·m	
	{kgf·cm}	{140 – 180 kgf·cm}	0.8 mm
ø3/8" (ø9.52 mm)	lbf·inch	300 – 360 lbf·inch	1/32"
	N·m	34 – 42 N·m	
	{kgf·cm}	{340 – 420 kgf·cm}	0.8 mm
ø1/2" (ø12.7 mm)	lbf·inch	430 – 540 lbf·inch	1/32"
	N·m	49 – 61 N·m	
	{kgf·cm}	{490 – 610 kgf·cm}	0.8 mm
ø5/8" (ø15.88 mm)	lbf·inch	590 – 710 lbf·inch	5/128"
	N·m	68 – 82 N·m	
	{kgf·cm}	{680 – 820 kgf·cm}	1.0 mm

- In order to prevent damage to the flare caused by over-tightening of the flare nuts, use the table above as a guide when tightening.
- When tightening the flare nut on the liquid tube, use an adjustable wrench with a nominal handle length of 7-7/8 in. (200 mm).

5-3. Insulating the Refrigerant Tubing

Tubing Insulation

- Thermal insulation must be applied to all units tubing, including distribution joint (field supply).
 - * For gas tubing, the insulation material must be heat resistant to 248°F (120°C) or above. For other tubing, it must be heat resistant to 176°F (80°C) or above. Insulation material thickness must be 13/32" (10 mm) or greater.
 - If the conditions inside the ceiling exceed DB 86°F (30°C) and RH 70%, increase the thickness of the gas tubing insulation material with one grade higher.

Insulation of the flare nuts

Attach the flare insulator (supplied) just like wrapping around the flare nut (supplied). Match the both slits of flare insulators for gas and liquid tubes facing upward. Tightly attach the end of the flare insulators to the tube cradle without any space. Then clamp the flare insulator with the clammers about 25/32" (20 mm) away from both ends.

If the exterior of the outdoor unit valves has been finished with a square duct covering, make sure you allow sufficient space to access the valves and to allow the panels to be attached and removed.



WARNING

Taping the flare nuts

Wind the white insulation tape around the flare nuts at the gas tube connections. Then cover up the tubing connections with the flare insulator, and fill the gap at the union with the supplied black insulation tape. Finally, fasten the insulator at both ends with the supplied vinyl clamps. (Fig. 5-8)

Insulation material

The material used for insulation must have good insulation characteristics, be easy to use, be age resistant, and must not easily absorb moisture.

After a tube has been insulated, never try to bend it into a narrow curve because it can cause the tube to break or crack. Never grasp the drain or refrigerant connecting outlets when moving the unit.



WARNING

5-4. Taping the Tubes

- (1) At this time, the refrigerant tubes (and electrical wiring if local codes permit) should be taped together with armoring tape in 1 bundle. To prevent condensation from overflowing the drain pan, keep the drain hose separate from the refrigerant tubing.
- (2) Wrap the armoring tape from the bottom of the outdoor unit to the top of the tubing where it enters the wall. As you wrap the tubing, overlap half of each previous tape turn.
- (3) Clamp the tubing bundle to the wall, using 1 clamp approx. each meter. (Fig. 5-9)





Fig. 5-7

NOTE

Tighten the clammers to prevent any condensation that may occur as the copper tubing is exposed.




Fig. 5-8




Fig. 5-9

NOTE

Do not wind the armoring tape too tightly since this will decrease the heat insulation effect. Also ensure that the condensation drain hose splits away from the bundle and drips clear of the unit and the tubing.

5-5. Finishing the Installation

After finishing insulating and taping over the tubing, use sealing putty to seal off the hole in the wall to prevent rain and draft from entering. (Fig. 5-10)




Fig. 5-10


Confirm the “Checkpoint” under the section “8. PRECAUTIONS ON TEST RUN” after installation of indoor and outdoor units, panels and electrical wiring.

6. FINAL PROCEDURE

Reinstall the removed part to be placed in its original position. (See the section “3-2. Preparation Before Installation”.)

Then install the accessory supplied side covers (L/R) on both sides of the indoor unit.

- Attach the supplied side plates.
Insert the side plates in the direction of the arrow and fix them with 2 screws once you’ve removed.



- Attach the accessory supplied side covers.
Slide the covers from the front side and attach to the claws of the latches.
Tighten the screws (accessory supplied).




Fig. 6-1

- Attach the air-intake grille.
When attaching the air-intake grille, perform the reverse procedure to removing the grille. Refer to the section “3-2. Preparation Before Installation”. Be sure to attach the safety string. Close the air-intake grille and fix the claws of the latches with the screws.




Fig. 6-2


7. HOW TO INSTALL TIMER REMOTE CONTROLLER OR HIGH-SPEC WIRED REMOTE CONTROLLER (OPTIONAL PART)

NOTE

Refer to the Operating Instructions attached to the optional Timer Remote Controller or optional High-spec Wired Remote Controller.

8. PRECAUTIONS ON TEST RUN

- Request that the customer be present at the time the test run is performed. Explain the Operating Instructions to the customer and then have the customer actually operate the system.
 - Be sure to pass the manual and warranty certificate to the customer.
 - Verify that the AC 208 / 230 V wiring is not connected to the terminal plate which is used to connect the inter-unit control wiring.
 - * If AC 208 / 230 V is accidentally applied to this terminal plate, the fuse (0.4A for both indoor and outdoor units) on the inter-unit control PCB will be tripped in order to protect the PCB. Correct the wiring connections, then disconnect the 2P connectors (blue, OC, CN040) which are connected to the PCB and connect the other 2P connectors (brown, EMG, CN044). (See the figure below.)
- If operation is still not possible with the brown connectors connected, cut the JP040.
(Be sure to turn OFF the power before performing this work.)



■ Checkpoint

	Checkpoint	Symptom	Check	Remark
1	Make sure whether indoor and outdoor units are correctly installed.	Fall, vibration, noise		
2	Make sure whether gas leakage is tested.	No cooling, no heating		
3	Make sure whether insulation is completed. (Refrigerant piping and drain piping)	Water leakage		
4	Make sure whether drain water is running smoothly.	Water leakage		
5	Make sure whether the power voltage matches the nameplate.	Inoperative, burnout		
6	Make sure whether there is miswiring or incorrect connection.	Inoperative, burnout		
7	Make sure whether the ground construction is completed.	Ground leakage		
8	Make sure whether the wire gauge is followed by the recommended specifications.	Inoperative, burnout		
9	Make sure whether the air intake and air outlet of the indoor and outdoor units are sealed by obstacles.	No cooling, no heating		

9. HOW TO INSTALL WIRELESS REMOTE CONTROLLER RECEIVER

NOTE

Refer to the Operating Instructions attached to the optional Wireless Remote Controller Receiver.

10. APPENDIX

Care and Cleaning

WARNING

- For safety, be sure to turn the air conditioner off and also to disconnect the power before cleaning.
- Do not pour water on the indoor unit to clean it. This will damage the internal components and cause an electric shock hazard.

Air intake and outlet side (Indoor unit)

Clean the air intake and outlet side of the indoor unit with a vacuum cleaner brush, or wipe them with a clean, soft cloth. If these parts are stained, use a clean cloth moistened with water. When cleaning the air outlet side, be careful not to force the vanes out of place.

CAUTION

- Never use solvents or harsh chemicals when cleaning the indoor unit. Do not wipe plastic parts using very hot water.
- Some metal edges and the fins are sharp and may cause injury if handled improperly; be especially careful when you clean these parts.
- The internal coil and other components of outdoor unit must be cleaned regularly. Consult your dealer or service center.

Air filter

It is recommended that the air filter be cleaned when the  (Filter) appears on the display.

After Cleaning

1. After the air filter is cleaned, reinstall it in its original position. Be sure to reinstall in reverse order.
2. Turn off the  (Filter) indicator from the screen. Refer to the Instructions attached to the optional Timer Remote Controller or optional High-spec Wired Remote Controller.

NOTE

Clean the filter frequently for best performance in the area of dusty or oil spots regardless of filter status.


<How to clean the filter>

1. Remove the air filter from the air-intake grille.
2. Use a vacuum cleaner to remove light dust. If there is sticky dust on the filter, wash the filter in lukewarm, soapy water, rinse it in clean water, and dry it.

<How to remove the filter>

Ceiling Type (T2)

1. Remove 2 attachment screws fixed with the latches. Take hold of the finger-hold on the air-intake grille and press it to the rear, and the grille will open downward.
2. Take hold of the finger-hold on the air filter, pull it toward you.



CAUTION

- Certain metal edges and the condenser fins are sharp and may cause injury if handled improperly; special care should be taken when you clean these parts.
- Periodically check the outdoor unit to see if the air outlet or air intake is clogged with dirt or soot.
- The internal coil and other components must also be cleaned periodically. Consult your dealer or service center.

Care: After a prolonged idle period

Check the indoor and outdoor unit air intakes and outlets for blockage; if there is a blockage, remove it.

Care: Before a prolonged idle period

- Operate the fan for half a day to dry out the inside.
- Disconnect the power supply and also turn off the circuit breaker.
- Clean the air filter and replace it in its original position.
- Outdoor unit internal components must be checked and cleaned periodically. Contact your local dealer for this service.

■ Troubleshooting

If your air conditioner does not work properly, first check the following points before requesting service. If it still does not work properly, contact your dealer or a service center.

● Indoor unit

Symptom		Cause
Noise	Sound like streaming water during operation or after operation.	<ul style="list-style-type: none"> ● Sound of refrigerant liquid flowing inside unit ● Sound of drainage water through drain pipe
	Cracking noise during operation or when operation stops.	Cracking sound due to temperature changes of parts
Odor	Discharged air is smelled during operation.	Indoor odor components, cigarette odor and cosmetic odor accumulated in the air conditioner and its air is discharged. Unit inside is dusty. Consult your dealer.
Dewdrop	Dewdrop gets accumulated near air discharge during operation.	Indoor moisture is cooled by cool wind and accumulated by dewdrop.
Fog	Fog occurs during operation in cooling mode. (Places where large amounts of oil mist exist at restaurants.)	<ul style="list-style-type: none"> ● Cleaning is necessary because unit inside (heat exchanger) is dirty. Consult your dealer as technical engineering is required. ● During defrost operation
Fan is rotating for a while even though operation stops.		<ul style="list-style-type: none"> ● Fan rotating makes operation smoothly. ● Fan may sometimes rotates because of drying heat exchanger due to settings.
Wind-direction changes while operating. Wind-direction setting cannot be made. Wind-direction cannot be changed.		<ul style="list-style-type: none"> ● When air discharge temperature is low or during defrost operation, horizontal wind flow is made automatically. ● Flap position is occasionally set up individually.
When wind-direction is changed, flap operates several times and stops at designated position.		When wind-direction is changed, flap operates after searching for standard position.
Dust		Dust accumulation inside indoor unit is discharged.
Poor cooling or heating performance		<p>The indoor unit is initially designed to control the indoor temperature detected by the built-in room sensor inside the indoor unit.</p> <p>Due to indoor unit installation position, however, the built-in sensor may occasionally sense temperature improperly; for example, temperature difference between the ceiling and floor, lighting apparatus, electric fan, windows or waist-high partition walls, etc.</p> <p>In this case, the unit does not operate properly at the desired temperature. You may change the use of the temperature sensor inside the indoor unit to that of the remote controller.</p> <p>Then the desired room temperature can be controlled properly.</p> <p>For details, consult your dealer.</p>

● Check Before Requiring Services

Symptom	Cause	Remedy
Air conditioner does not run at all although power is turned on.	Power failure or after power failure	Press ON/OFF operation button on remote controller again.
	Operation button is turned off.	<ul style="list-style-type: none"> ● Switch on power if breaker is turned off. ● If breaker has been tripped, consult your dealer without turning it on.
	Fuse blow out.	If blown out, consult your dealer.
Poor cooling or heating performance.	Air intake or air discharge port of indoor and outdoor units is clogged with dust or obstacles.	Remove dust or obstruction.
	Wind speed switch is set to "Low".	Change to "High" or "Strong".
	Improper temperature settings	Refer to "■ Tips for Energy Saving".
	Room is exposed to direct sunlight in cooling mode.	
	Doors and /or windows are open.	
	Air filter is clogged.	Refer to "■ Care and Cleaning".
	Too much heat sources in room in cooling mode	Use minimum heat sources and in a short time.
Too many people in room in cooling mode	Reduce temperature settings or change to "High" or "Strong".	

If your air conditioner still does not work properly although you checked the points as described above, first stop the operation and turn off the power switch. Then contact your dealer and report the serial number and symptom. Never repair your air conditioner by yourself since it is very dangerous for you to do so. You also report if the inspection mark  and the letters E, F, H, L, P in combination with the numbers appear on the LCD of the remote controller.

■ Tips for Energy Saving

Avoid

- **Do not block the air intake and outlet of the unit. If either is obstructed, the unit will not work well, and may be damaged.**
- Do not let direct sunlight into the room. Use sunshades, blinds or curtains.
If the walls and ceiling of the room are warmed by the sun, it will take longer to cool the room.

Do

- Always try to keep the air filter clean. (Refer to "Care and Cleaning".) A clogged filter will impair the performance of the unit.
- To prevent conditioned air from escaping, keep windows, doors and any other openings closed.

NOTE

Should the power fail while the unit is running

If the power supply for this unit is temporarily cut off, the unit will automatically resume operation once power is restored using the same settings before the power was interrupted.

- NOTE -

